


HEINRICHSOHN

Bedienungsanleitung / User manual

Modell / Model: HS1016



Einstellen des Datums:

Die Krone vorsichtig auf Position 1 herausziehen und solange nach links drehen, bis ein Tag vor dem gewünschten Datum angezeigt wird. Danach die Krone wieder auf Position 0 drücken und mit dem Einstellen der Uhrzeit fortfahren.

Setting the date:

Carefully pull out the crown to position 1 and turn it to the left as long as, until one day before the desired date will be displayed. Then push the crown back to position 0 and proceed with setting the time.

Einstellen der Uhrzeit:

Die Krone vorsichtig auf Position 2 herausziehen und solange im Uhrzeigersinn drehen, bis die richtige Uhrzeit und das richtige Datum angezeigt wird. Danach die Krone wieder auf Position 0 drücken. Bitte beachten Sie, daß sich das Datum nach 24 Stunden zwischen 22 und 2 Uhr automatisch erhöht.

Setting the time:

Carefully pull out the crown to position 2 and turn it clockwise until the correct time and the correct date is displayed. Then push the crown back to position 0. Please note that the date is automatically increased after 24 hours between 10 pm and 2 am.

Service:

ILA Uhren GmbH - Otto-Hue-Strasse 42A - 45772 Marl (Germany)
Tel./Phone: +49236556059 - Email: shop@heinrichssohn.de